How to buy

- **1. Choose** standard or low-base frame.
- 2. **Select** a model with or without scale.
- **3. Choose** thigh straps. Then select additional accessories as your needs require.

			्रवा ^न	K310 Standard (better for gait training)		K320 Low-base (fits under low beds)	
Requi	Frame includes one battery, one battery charger, accessories tote and charger power cord (international power cords available on request)	СНООЅЕ	Frame with scale	K301		K321	
Required components		OSE	Frame	K302		K322	
	Thigh straps (pair)	CHOOSE	Narrow	K308		K308	
			Wide	K338		K338	
Optional accessories	New! Switch pole			K666		K666	
	Arm supports (pair)		Small arm prompts	K305		K305	
		CHOOSE	Large arm prompts	K315		K315	
			Arm platforms	K397		K397	
	Pelvic support		Small	K306		K306	
		CHOOSE	Medium	K316		K316	
			Large	K326		K326	
	New! Hip positioner	CHC	Small	K667		K667	
		СНООЅЕ	Large	K668		K668	
	New! Hip positioner pad	снооѕе	Small	K541		K541	
		OSE	Large	K542		K542	
	Additional battery (recommended for institutional use)			K307		K307	
	Additional thigh straps		Narrow single	K318		K318	
		댅	Narrow pair	K308		K308	
		СНООЅЕ	Wide single	K328		K328	
			Wide pair	K338		K338	
	Directional lock (pair)			K319		K324	
	Removable back belt					K327	
Tota	Total Control of the					K320	