


The Total Solution for Pool and Spa Access



WOOD DECK ANCHOR INSTALLATION INSTRUCTIONS

EZ & POWER EZ POOL LIFT

400 LB. MAXIMUM CAPACITY

MANDATORY: LEAVE THIS MANUAL WITH LIFT OWNER

WARNING-

IMPORTANT SAFETY INSTRUCTIONS

- 1. READ AND FOLLOW ALL INSTRUCTIONS. LIFT SAFETY CAN ONLY BE ENSURED IF THE LIFT IS INSTALLED AND OPERATED PROPERLY - ACCORDING TO THESE INSTRUCTIONS.
- 2. TO REDUCE THE RISK OF INJURY, DO NOT PERMIT CHILDREN TO USE THIS PRODUCT UNLESS THEY ARE CLOSELY SUPERVISED AT ALL TIMES.
- 3. DO NOT PERMIT CHILDREN TO PLAY ON OR AROUND THIS PRODUCT.
- 4. NEVER APPLY DIRECT WATER PRESSURE TO THE ELECTRONIC COMPONENTS.
- 5. SAVE A COPY OF THESE INSTRUCTIONS IN A SAFE AND EASILY ACCESSIBLE PLACE.

AQUA CREEK PRODUCTS 9889 GARRYMORE LANE MISSOULA, MT 59808 1-888-687-3552


FAX: 406-549-2602

PACKING LIST:

ITEM#	QTY.	DESCRIPTION
1	1	WOOD DECK ANCHOR
2	1	TAMPER RESISTANT LID

INSTALLATION INSTRUCTIONS:

- 1. Find the desired location for the lift. The setback (the distance from the center of the anchor to the pool wall) must be 20" or less as shown in **FIGURE 1**.
- 2. Reinforce the deck using 2X6 material as shown in **FIGURE 2**, **FIGURE 3** and **FIGURE 4**. The reinforcing boards should be about 2-feet long so that they extend at least 7" past the mounting bolts on each side as shown in **FIGURE 1**.
- 3. Drill a 3" hole through the decking at the desired location for the body of the anchor.
- 4. Place the WOOD DECK
 ANCHOR in the 3" hole
 (upside down) and spin it until
 the four (4) mounting holes line
 up in a square pattern parallel
 with the joists & reinforcing
 boards as shown in FIGURE 1.
 Mark the four (4) mountingbolt hole locations. Remove the
 anchor.
- 5. Drill 7/16" holes at the marked locations. Make sure to drill straight down, perpendicular to the deck, all the way through the deck and the reinforcing boards.
- Install the WOOD DECK
 ANCHOR using four (4) 3/8" x
 4" carriage bolts and 3/8"
 locking nuts (not included).
 NOTE: For thick decks the bolts might need to be longer.



*NOTE: Bond anchor to bonding grid with 8-AWG solid copper wire per local electrical codes as required.

